

AIRFIELD LAMPS

CROSS-REFERENCE/REPLACEMENT GUIDE

GE types	Equivalent NARVA types	NARVA part no.	SLI types	Equivalent NARVA types	NARVA part no.
EVV	6128	58355	L2352 / 24522	6107LL	58306
EWV	6292	58365	L2354 / 21518	6139LL	58378
EXL	6112LL	58312	L2358 / 21496	6101LL	58304
EXM	6134LL	58325	L2359 / 21497	6106LL	58305
EZL	6372LL	58374	L2362 / 24526	6103	58307
Q200/T4/CL	6372LL	58384	L2368 / 21498	6105	58308
Q6.6A45PK30d-m	6303LL	58326	L2369 / 21499	6108	58310
Q6.6A45PK30d-f	6130LL	58328	L2370 / 21500	6102	58302
Q6.6A100PK30d-m	6116LL	58347	L2373 / 21483	6144	58334
Q6.6A100PK30d-f	6121LL	58349	L2500 / 21757	6112LL	58312
Q6.6A150PK30d-m	6392LL	58368	L2501 / 21686	6134LL	58325
Q6.6A150PK30d-f	6118LL	58369	L2502 / 24529	6292	58365
Q6.6A200PK30d-m	6117LL	58377	L2504 / 21696	6372LL	58374
Q6.6A200PK30d-f	6139LL	58378	L2505 / 24531	6128	58355
6,6A/T10P	7654C or H	67845 / 58320	L2511 / 22214	6123	58323
6,6A/T10/1P	7669C or H	67830 / 58318	L2513 / 22212	6343	58343
6,6A/T10/2P	7668C	67851	L2514 / 22211	6373	58373
6,6A/T14/3P	6936C	67861	L2517 / 21480	6315	58315